



# CLINCHER® IV AND V

## PHOTO BAND


### HOW TO APPLY




1 Push the male half of the double-headed grip fastener (the prongs) through the single pair of holes located at the data end of the band.



2 Put the band around the recipient's wrist, keeping the tip of your forefinger under the band to hold the prongs in place. Tighten band until it fits snugly, then push the prongs through the holes in the band. Wristband should fit snugly and comfortably like a watchband.




3 Place the female half of the fastener (the plate) over the prongs protruding through the holes.




#### 4A For Metal Fastener Only

Crimp the fastener firmly with the fastening tool.



#### 4B For Plastic Snap Only

Press firmly together until both pieces lock with a snap.



5 Cut off the excess material as close as possible to fastener.